



Banff-AL GNSS Receiver User Manual

Table of Contents

Chapter 1 Introduction	4
1.1 About Banff-AL	4
1.2 Receiver Features	4
Chapter 2 User Interface	6
2.1 Environmental Requirements	6
2.2 Front Panel	6
2.3 Back View	6
2.4 Lower Housing	7
2.5 Power Supply	7
Chapter 3 RTK Workflow	8
3.1 Installation of GeoPad	8
3.2 Create a New Project	8
3.3 Device Connection	16
3.3.1	16
NFC Connection	16
3.3.2	16
Bluetooth Connection	16
3.4 Quick setup Banff-AL receiver	19
3.4.1	20
Mode 1 – Internal Radio Mode(Banff-AL Base + Banff-AL Rover)	20
3.4.2	20
Mode 2 – PDA CORS Mode(Single Banff-AL Rover)	26
Chapter 4 RTK Survey-field Data Collect	32
4.1 GeoPad Top Status Bar Introduction	32
4.2 Point Survey	33
4.3 Calibrate Point	39
4.4 Localization	43
4.5 Tilt Survey	51
4.6 *Laser Survey*	53
4.7 Detail Survey	58
4.8 Control Point Survey	59
4.9 Point Stakeout	60
4.10 *Visual AR Stakeout*	66
4.11 Line Stakeout	70
4.12 CAD Mapping and Stakeout	72
4.13 DSM Stakeout	75
4.14 Points Database	75
4.15 Data Export/Import	77
4.15.1 Import points data	77
4.15.2 Export points data	79
Chapter 5 Static Survey	82
5.1 Static Data Collection	82
5.2 Static Data Download	85

Proprietary Notice

Information in this document is subject to change without notice and does not represent a commitment on the part of 3A GEOCANADA. The software described in this document is furnished under a license agreement or non-disclosure agreement. The software may be used or copied only in accordance with the terms of the agreement. It is against the law to copy the software on any medium except as specifically allowed in the license or non-disclosure agreement.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the express written permission of a duly authorized representative of 3A Geocanada Ltd.

Corporate Office

3A GEOCANADA

Address: 255 Spinnaker Way #10, Concord, ON L4K 4J1, Canada

Tel: +1 (437) 450-0099

Website: www.3ag-positioning.com

E-mail: sales@3ageocanada.com

Copyright Notice

This is the V1.0 (Dec, 2024) revision of the Banff-AL GNSS Receiver User Guide. It cannot be copied or translated into any language without the written permission of 3AG.

©2024 3A GEOCANADA All rights reserved.

Chapter 1 Introduction

The 3AG Banff-AL GNSS Receiver (hereinafter Banff-AL) User Guide is aimed to help you get familiar with the Banff-AL receiver and start your project effectively. We highly recommend you to read this manual before surveying, even you have used other GNSS RTK receivers before.

1.1 About Banff-AL

With high precision GNSS module inside, Banff-AL GNSS receiver can be applied in RTK mode with all GNSS constellations. Banff-AL receiver has ultra-small size and strong anti-interference ability to make it possible to work even in harsh environments. It is the ideal RTK/GNSS product for surveyors.

To make surveying smarter, 3AG has added a starlight-grade camera and a precise laser module to the Banff-AL GNSS receiver, achieving deep fusion of multiple sensors.

While shrinking the device to the palm size, Banff-AL provides an advanced GNSS engine, immersive AR stakeout, non-contact laser surveying, 60° tilt IMU, 15km enhanced UHF, and rich features to empower your tasks.

1.2 Receiver Features

The 3AG Banff-AL GNSS Receiver key features:

- Ultra small and super light
- Size: $\Phi 107\text{mm} \times 58.7\text{mm}$
- Weight: 547g
- 1408 channels of simultaneously signal tracking
- Fast charging via Type-C interface
- Cable-free Bluetooth wireless technology
- IP67 waterproof & dustproof
- Full base/rover interoperability
- Integrated IMU sensor
- Starlight-grade Camera, HD Capture in Weak Light Environment
- Laser Injection Power: 2mW~3mW

Chapter 2 User Interface

This chapter provides general information on environmental requirements, setup, power supply and connection of the Banff-AL receiver.

2.1 Environmental Requirements


To keep the receiver with a reliable performance, it is better to use the receiver in safe environmental conditions:

- Operating temperature: -40°C to +65°C
- Storage temperature: -55°C to +85°C
- Out of corrosive fluids and gases
- With a clear view of sky

2.2 Front Panel

Receiver front panel contains 3 indicator LEDs and 1 Power button.

Front Panel



2.3 Back View

The rear of the Banff-AL contains a laser transmitter and a laser receiver.

Receiver Back



2.4 Lower Housing

Receiver lower housing contains a Type-C port, TNC connector and a camera.



2.5 Power Supply

The receiver is equipped with internal batteries.

- 4200 mAh, up to 12 hours working time
- Fast charge of 3 hours charging time

Chapter 3 RTK Workflow


This chapter introduces how to conduct RTK Survey with GeoPad Software. GeoPad is professional Android-based surveying software developed by 3AG team. GeoPad is fully functional as a field surveying software, equipped with complete work modes and necessary functions for surveyors. If you need post-processing software, please contact the support email at <[support email]> for assistance.

3.1 Installation of GeoPad

GeoPad has been pre-installed on 3AG data collector before shipping.

3.2 Create a New Project

Click **Project Manager**, click the **New** to create a new project file and input project name, set coordinates systems parameters and click **OK** to save the project.





Operator	Input
Notes	Input
Date Created	2024-12-26 14:36:55

More

Use Last Project Coordinate System ☐



10:01 37%

← New Project

Basic Information **Coordinate System Parameters**

Coordinate System Type Local System >

Name Default ✕

Ellipsoid Parameter

WGS84 >

Semimajor Axis:6... 1/f:298.257223563

ITRF Conversion

None >

Projection Parameter

UTM >

Central Meridian E123°00'00"

Datum Parameter


None >

Back OK

Our software has added many countries' coordinate systems, you can find what you need by country name or coordinate system name.


The following steps give an example of how to find predefined coordinate systems of our GeoPad software.

Click the button located after **Name** in Coordinate System Parameters interface.





In the Coordinate System Favorites interface, click the **Template** below to enter the Predefined Projections interface.







Click **Country** to select the country name or enter a keyword after **Search** to find it.








After finding the required coordinate system, click **Apply** to add it to coordinate system parameters, click OK to apply it to the current project.






If you don't find what you need in Predefined Projections, you can click **Add** or **Import** to create new coordinate system.







3.3 Device Connection

3.3.1

NFC Connection


Equipped with an NFC chip, users can easily connect the Banff-AL receiver to the data collector with just one touch, as shown in the figure below.



3.3.2

Bluetooth Connection

After creating a new project, switch to **Device** interface, click **Communication**.



Select the corresponding parameters according to the following requirements

Device Type: GNSS


Device Manufacturer

Mode Type: RTK (Banff-AL)

Connection Type: Bluetooth

Make sure controller Bluetooth turned on, click below Currently Paired Device to find SN of your Banff-AL receiver. Click Connect.

After connecting Banff-AL receiver, you can check the information of the receiver (like firmware version) in **Device Information**.



Tips: If you fail to connect with receiver through GeoPad, you can follow the prompts to enter the system Bluetooth settings interface of the PDA/data collector to ensure that the Bluetooth pairing is successful. Sometimes you need to cancel the device Bluetooth pairing, restart the receiver or GeoPad software and pair again.

3.4 Quick setup Banff-AL receiver

Please follow the instructions below to quickly set up your Banff-AL receiver according to the kit type you purchased.

For Banff-AL **Base & Rover Kit**

Refer to Section 3.4.1 Internal Radio Mode for detailed setup instructions.

For Banff-AL Rover Kit

Refer to Section 3.4.2 PDA CORS Mode for detailed setup instructions.

Ensure that you follow the appropriate section based on your kit to achieve optimal performance of your Banff-AL receiver.

3.4.1

Mode 1 – Internal Radio Mode (Banff-AL Base + Banff-AL Rover)

Equipped with an NFC chip, users can easily connect the Banff-AL receiver to the data collector with just one touch, as shown in the figure below.

If you've purchased 2 units of Banff-AL GNSS receiver, please select one Banff-AL as base and the other as rover. During configuration, you need to connect your PDA device or data collector to the base and rover respectively.

When work as a Base station, GeoPad supports transmit the correction data in Internal Radio mode. **Internal Radio**: This mode uses internal radio to transmit the correction data from Base to Rover. You need to set Base and Rover with the same protocol and frequency.

Tip: Banff-AL GNSS receiver has two radio versions, U and LU version. U version radio supports many radio protocols whether base or rover, but data transmission distance can only reach 3-5 kilometers under ideal environment; LU version radio only supports CSS radio protocol when set as base, and also supports many radio protocols including CSS radio when set as rover, but data transmission distance can reach 10-15 kilometers under ideal environment. Please contact the sales to confirm which radio version to purchase.

- Protocol: U supports TRIMTALK, TRIMMK3, TT450S, TRANSEOT, SATEL and LU supports only CSS for base transmission
- Frequency: select a channel or customize a frequency, the range of frequency is 410-470MHz.
- Baud rate: 9600 and 19200. This option is to set the baud rate of lemo port.
- Power: High and low (low power will reduce the RTK range)

Tips: Condition of the base station setup

Environment:

Clear outdoor sky view, free from obstructions

Place GPS and radio antennas as high as possible to reduce signal interference and increase range

Avoid:

Obstacles: buildings, vehicles, towers, trees, etc.



Interference: high-power radar, TV, cellular towers, power lines or electrical facilities


The following steps give an example of how to configure internal radio base mode.

NOTE:


Remember connect the whip antenna to both your base station and rover when you set internal radio work mode.

1. Go to **Device>>Base**. Set **Base ID** and choose the **Diff Mode** firstly.





2. Click Base Startup Mode to select the base startup way



Single Point: Start the base station at unknown coordinates



Assigned Base Coordinates: Start the base station at known coordinates, and you need to enter the latitude, longitude and the height

Use **Current Coordinates:** Automatically start the base station at current coordinates.

Note: Please setup the base station at a known point. Select Base Startup Mode as Assigned Base

Coordinates and input the known point coordinates. Make sure the current coordinates of the instrument is within 50 meters of the known point coordinates.

3. Set Data **Link** as **Internal Radio**. Set parameter settings, Channel, Frequency, Protocol, Baud Rate and Power.




4. When start Base succeed, it will show as below in GeoPad.




After base settings, please disconnect the base device and then search for the SN of rover to connect and configure the rover device. Select the same protocol and frequency with the Base.


The following steps give an example of how to configure internal radio rover mode.

1. Go to **Device**>> Rover. Set Data **Link** as **Internal** Radio.






2. **Parameter Settings.** Set Channel, Frequency and Protocol the same as the Base.



3. **Base Coordinates Change Alert:** GeoPad will alert when the base station coordinates change while you are working. This may be because the rover is mistakenly connected to another base station or the base station has been moved.



4. Click **Apply** to start the Rover mode.

After completing the configuration, please check the RTK status in the top status bar. Once the status changes to "FIXED" and the differential delay "age" is within the range of 1-2 seconds, you have obtained reliable centimeter-level RTK positioning.



3.4.2


Mode 2 – PDA CORS Mode (Single Banff-AL Rover)

Equipped with an NFC chip, users can easily connect the Banff-AL receiver to the data collector with just one touch, as shown in the figure below.

When works as a rover, GeoPad supports receive the correction data in Phone Internet Mode.

Phone Internet: This mode uses the phone internet to transmit the correction data from Base to Rover. Please make sure the PDA device is in good network conditions, such as 4G (SC200 data collector can obtain a 4G network signal by inserting a SIM card), WiFi or hot spot.

1. Go to **Device>> Rover**. Set Data Link as Phone **Internet**.




2. Set **Connect Mode**, for Banff-AL receiver supports NTRIP and TCP Client.

CORS Settings. Input the server IP, Port, User and Password in the CORSS Settings.

Note:

The IP & port in the picture is only for example, please enter your local CORS account instead. You can purchase a third-party RTK corrections service account in your local area to obtain an RTK FIX solution.

3. Click **Get** button on the right to get the mountpoint list and choose the mountpoint.




Note:


The mount point "Office" in the figure is an example. Please find out the appropriate mount point via the website of your local NTRIP/CORS provider. Make sure that the baseline doesn't exceed 50km.

4. Click **Start** button on the right to receive data from CORS/RTK correction service. Then you can see


the rover is receiving data.



5. **Auto connect to network:** When this option is opened, GeoPad will connect to network automatically so that user don't need to click start to connect network.



6. **Base Coordinates Change Alert:** GeoPad will alert when you connect with different base station. When you are using VRS, please do not turn this on.



7. Click **Apply** to start the rover mode. After completing the configuration, please check the RTK status in the top status bar. Once the status changes to "FIXED" and the differential delay "age" is within the range of 1-2 seconds, you have obtained reliable centimeter-level RTK positioning.

RTK Survey-field Data Collect

This section describes the basic survey functions of GeoPad, including Point Survey, Laser Survey, Point Stakeout, AR Visual Stakeout, CAD Mapping and etc.

4.1 GeoPad Top Status Bar Introduction

After completing your Banff-AL RTK setup, check current RTK solution status at the top of the GeoPad software.





The satellite icon shows calculated satellites number/tracked satellites number. You can click it to check satellite map and more information.



Age means the time since the last differential data was received. When connecting to a CORS account for measurement work, please ensure the **Age** is within the range of 1-2. When using the radio mode for measurement work, please ensure the **Age** is within the range of 2-5. A high **Age** will result in poor measurement point accuracy.



There are HRMS and VRMS on the top of the interface, click it you can check more details.

4.2 Point Survey

In the Survey interface, click **Point Survey** and enter point name, code and antenna height, then click




to measure a point.



Note:

Our software supports 3 antenna measuring types.




Pole Height: Typically, select the Antenna Measuring Type as Pole Height and enter the height of your centering pole.

In the floating window of the survey interface, you can see the display information. The default display information is NEH and Base distance, and click the floating window you can set them as you need. You




can also click

to enter the display information settings interface and select the information you need to display. Except default display information, GeoPad supports Longitude, Latitude, Altitude, etc.



- Click to select different map types or do map calibration. GeoPad supports Google Map (Standard Map/Satellite Map), OpenStreetMap and WMS Map.



- Click
to jump to map center.




- Click
to show all points on the interface.



- Click

to enter the point database and view the coordinates of the measured points. You can add, recover, import and export data. After selecting a point, you can view the details and take notes or take photos.



The screenshot shows the 'Points Database' app interface. At the top, there's a status bar with the time 10:05 and 95% battery. Below it, a header bar with a back arrow, the title 'Points Database', and user information 'NEH BLH'. A search bar with the placeholder 'Name' and an 'Input' button is present. The main content is a list of three points, each with a location pin icon, name, coordinates, and timestamp.


Name	Input
Pt3 Smooth Point	T:2024-11-26 10:05:20.280
N:3449293.743	Elev:13.591
E:336991.812	Code:
Pt2 Smooth Point	T:2024-11-26 10:05:15.118
N:3449293.819	Elev:13.561
E:336991.986	Code:
Pt1 Smooth Point	T:2024-11-26 10:05:08.884
N:3449293.783	Elev:13.495
E:336991.881	Code:



- Click

to enter Settings interface


In **Settings** interface, you can modify **Tolerance Setting** such as solution limit, HRMS limit, VRMS limit and etc. and modify Smooth parameters and configure **Settings** options.



In **Display Info** interface, you can set the display information to the floating window, such as longitude, latitude, altitude, etc.




In **Tool Bar** interface, you can add or delete options that displayed on the point survey interface. You can customize the interface layout to suit your usage habits.



4.3 Calibrate Point

When changing the position of the base station, there will be offsets between surveying points base on different base stations. Users can use the Calibrate Point to calibrate the offset.


Go to **Project>Calibrate** Point. Add a point measured under the previous base station as **Known Point Coordinates** and measure the same point under current base station as GNSS **Point Coordinates**.





For the GNSS Point Coordinates, you can click the surveying icon to measure under the current base directly.
 Note: Please confirm the RTK status is FIXED.





Or measure the GNSS point under the current base station in advance and click to select from the point database.





Then click **OK** to complete the Calibrate Point.




4.4 Localization

When starting a new project, if you are using the local small-scale coordinate system, you can use this function to transform the geodetic coordinates system to your local system.

Go to **Project>Localization**, add at least 3 pairs of points for the Localization.


Note:

A pair of points are the known local coordinates and the surveying coordinates of the same point.





Click **Add** to add the corresponding pairs. Input the Known Point Coordinates.






Then select the corresponding GNSS coordinates of the known point.









Add the remaining point pairs in sequence. You can also enter the known point in point database in advance and select the input points.







After adding all the point pairs, click **Calculate**.





Select the convert method and the accuracy limit according to your project requirements.









You can click Export Report to save the projected coordinate system parameters. Click **Apply** to apply the localization.



4.5 Tilt Survey

The Banff-AL GNSS receiver has a built-in IMU module that supports tilt surveying up to 60°. The system will accurately calculate the actual offset based on the tilt angle, reducing the user's burden on centering pole at each measurement.



The tilt function option

will appear in each survey/stakeout function interface. You can click to turn this function on/off.

Tilt initialization is required when using it for the first time or when its calibration expires.

The following steps give an example of how to use tilt survey.



1. Open IMU: Go to survey >> Point Survey >> click the button to open.

After clicking the tilt IMU button, the system will prompt you to check the antenna information, please check whether the antenna height is correct.



2. Initialization

After clicking the IMU button, you can follow the guidance on the interface to complete it.

During operation, ensure that the receiver can search for satellites and obtain a fixed RTK solution. Note: If the receiver is powered off or reset, it will need to be reinitialized.



In survey interface, you can find the bubble and angle value showing how you tilt the pole in real time. To ensure the accuracy, please keep the tilt angle less than 60°. When the pole tilts within 60°, the built-in IMU precisely calculates the actual offset, the accuracy of which can be accurate to $\pm 2.5\text{cm}$.




Tips: Do not shake or rotate the receiver violently, otherwise you need to re-initialize.


4.6 *Laser Survey*

1. Connect Banff-AL receiver to GeoPad software via Bluetooth and ensure a fixed RTK solution.
2. Before using laser surveying, you need to complete IMU initialization for Banff-AL according to the software

prompts. When the IMU icon shows Ready, the accuracy of the laser surveying is accurate.

Tips: Laser surveying is based on IMU, so shake It more times to ensure that the IMU is initialized successfully.





3. Turn on the laser surveying function in the Point Survey interface.




Then the Banff-AL laser can be clearly seen.



Tips: It is recommended to use a bipod for laser survey to reduce the shaking caused by human factors and lead to inaccurate precision.



4. Now click the measure button and you can perform laser survey normally. The points measured using the laser can be viewed in the Points Database (Please refer to section 4.14 to find it).



Tips: The laser of Banff-AL can reach about hundreds of meters, but it does not mean that it can measure so far. 3-5 meters is the best accuracy.

4.7 Detail Survey

After completing your Banff-AL RTK setup, check current RTK solution status at the top pf the GeoPad software.

In detail survey interface, both local coordinates and Latitude/Longitude will be displayed when measuring.



- Click
to start or stop collecting data



- Click
to set settings, display info and tool bar.



- Click
to check point database; you can add note, info, arrow drawing and photo.



- Click
to open IMU to do tilt survey.




- Click


to open Fast Code Survey. You can input Remark and Code into it, then click the button that just created to start quick-collecting.



4.8 Control Point Survey

By measuring the coordinates of the same point multiple times and taking the average, you can get more accurate coordinates. This function is usually used to measure control points.





- Click  to start or stop collecting data.



- Click  to set settings, display info and tool bar.





- Click  to check point database; you can add note, info, arrow drawing and photo.



4.9 Point Stakeout

Go to **Stake point** interface, add or import the point coordinates you need to stake out, you can also click Button Library to select from the point database.




- Click Add to input coordinates



- Click button library to choose one.



- Click Import to import point data in different file types. You can also define a new format according to your needs.



Select a point to stake out. GeoPad provides a navigation map while staking out points/lines. The software alerts you when you approach the target point to the set range value.

For Banff-AL receivers, you can use the IMU stakeout feature. In IMU stakeout, you can turn on the IMU feature without keeping the receiver perpendicular to the ground. The maximum tilt angle is 60°.



There is a direction prompt on the floating window.



- Click
to start or stop stake points



- Click
to open or close IMU



- Click
to scale automatically to full map



- Click
to jump to current point



- Click
to jump to next point



- Click

to jump to previous point




- Click

to set stake out settings, display info and tool bar, you can edit the prompt range and range error



- Click

to open compass





4.10 *Visual AR Stakeout*




After completing your Banff-AL RTK setup, check current RTK solution status at the top of the GeoPad software.

1. Get a fix solution.


When using Visual AR Stakeout, you need to connect to Banff-AL's WIFI. So if you are using CORS (using Phone Internet to obtain the network), please insert a SIM card into the controller instead of connecting the controller to WIFI or hotspot. If you are using radio communication (no network required), you don't need to consider these.

2. Using Visual AR Stakeout also requires IMU initialization.


3. After importing stakeout points, enter the staking interface.




Then click the AR staking icon, and the controller will automatically jump to WIFI connection interface. Select Banff-AL from the WIFI list and **enter the password 12345678 to connect**. After connecting, return to the stakeout interface to see the image in the Banff-AL camera






4. Follow the software prompts to ensure the receiver is facing backwards. The software will prompt you the location of the stakeout point based on the camera



When you approach the point to be staked, the software will mark the location on the screen.



At this time, align the tip of the rod with the position of the stakeout point. Then click the survey button to stake out.



4.11 Line Stakeout

Go into Line Stake interface, add or import lines you need to stake out.



- Click Add to input line parameters
- Click Import to import point data in different file types. You can also define a new format according to your needs.



Choose a line to stakeout, set Offset, Cross-Section Slope and Stakeout by Pile-to-Pile Coordinate parameters.




- Click
to jump to next line



- Click
to jump to previous line

4.12 CAD Mapping and Stakeout


When using this function for the first time, the CAD interface has no layers and floating window to display the features you need to stake.



- Click
to create or import a CAD file, supporting *.dxf, *.dwg format.




- Click
to draw features, there are 12 types and methods you can choose, follow the prompts and draw.



- Click

on the Find tools. They can help you to work smoothly. For example, to find the intersection points of neighboring circles.





In the CAD interface, you can choose a feature you want to stake, it will show up in blue. You can know the details about it, including length, start point, end point and center point. And choose the way to stakeout.

- Setting: Set the method of stake out, offset distance, interval etc.
- Start station: If you set the start station as 5m, then the final mileage will plus5m.
- Offset: If you set the offset 5m, then you will stake the line 5m away from the line you choose. The plus and minus represent different sides of the line.
- Setting out by pile by coordinate: including station number, station distance and segment
- Station distance: Stake the line at a specified distance, for example, if the line is 40m, you set the specified distance as 8m, then you will stake the line at 8m distance every segment.
- Segment: For example, if you set the segment as 4, then you will stake the line at 4 segments, every segment length is the same.
- Station number: You will stake the line at the station at each interval point. You can stake it out according to the direction.
- Key node: It will stake out the line with starting point, ending point, midpoint, fold point, etc.


4.13 DSM Stakeout

You can stakeout a surface by staking out elevation of each point on the surface.

If you haven't used a surface file before, you need to create one by adding, importing, or selecting from the database.

You can get a preview map of the surface after adding points and don't forget to save it.

At the content list interface, you can find the surfaces you created, and you can edit, share and stake them.




If the current position is not within the design surface, it will prompt “Out of surface!”. If the current position is within the design surface, it will show the fill or excavation value.

4.14 Points Database

The points, which are surveyed, staked, added, imported, and input from display map, will be stored in point database. The surveyed points will be shown under one base while surveying. Also, no matter where you need to select a point, all the points of the database are available.





- Add: Support to add Input Point, and display type supports local coordinate and geodetic coordinate
- Recover: After deleting the points, you can recover them in deleted points interface
- Import: Import points by different formats of files
- Export: Export points by different formats of files
- Search: Enter the name of the point you want share or delete

Tap any point to view the detailed information. The information includes antenna height, solution status, WGS84 Coordinate, local grid coordinate, base id and measure time. If the point has been calibrated, the offset parameters will be displayed.





4.15 Data Export/Import

GeoPad supports to export/ import data including grid coordinate, Lat/Lon coordinate with various data format, and supports importing *.dat/*.csv/*.kml file and exporting result of *.dxf/*.kml/*.shp/*.xls/*.csv.

4.15.1 Import points data

Tap Import data in project interface, there are some predefined data formats, click More to get more predefined formats.



- Data Type: support point database, transformation parameters file and code library
- Import File Format: support *.csv, *.dat, *.txt, *.kml, etc.

- Distance Unit: support meter, US survey feet and international feet

Besides, you can click now to create a User defined type.

11:45 82%

← Custom Format

Format Name Input

Extension Name dat >

Field Delimiter Comma(,) >

Custom Format Description

Options

(Null)	Point Name
Code	Northing
Easting	Elevation
Latitude	Longitude
Altitude	

Backspace OK

- Format name: Enter the name for the format
- Extension name: support *.csv, *.dat, *.txt, *.xlsx format
- Delimiter: support comma (,), semicolon (;), space (), tab (Tab)

Click to choose elements in the options list, click backspace to eliminate the previous element selected. The elements include: code, northing, easting, elevation, latitude, longitude, altitude. Choose one format to import data. The default export path is internal storage/ GeoPad /import. You can also change to any other path where the file is. Click preview to take an inspection whether the format is right.

11:53 81%


← Preview

Point Name	Northing	Easting
Pt1	3449294.210	336993.1
Pt2	3449294.201	336993.1
Pt3	3449294.399	336993.1
Pt4	3449294.391	336993.1
Pt5	3449294.346	336992.1
Pt6	3449293.926	336994.1
Pt7	3449293.816	336994.1
Pt8	3449293.737	336994.1
Pt9	3449290.485	336994.1
A	3449306.409	336851.1
A1	3449306.407	336851.1

Cancel OK

4.15.2 Export points data

Tap Export in Project interface to export point data. Also, click More formats to export the survey points in various formats like stake points/ lines, DXF, SHP, KML, RAW, RW5, HTML, CASS feature result.



- Export Path: the default export path is internal storage/ GeoPad /export; you can also change to any other path where the file is
- File Name: support project name, operator, data, data time
- Export File Format: support *.csv, *.dat, *.txt, *.kml, etc.
- Distance Unit: support meter, US survey feet and international feet
- Road section data: open to export road section data

Besides, you can click New to create a user defined type. The elements include: id, name , code, latitude, longitude, altitude, northing, easting, elevation, N, E, Z, type, local time, UTC time, solution status, AGE, max delay, min delay, use satellites, tracked satellites, cut-off angle, mount point, measurement method, repeat, start data, end time, RMS, HRMS, VRMS, PDOP, VDOP, speed, heading, antenna type, measuring type, measuring height, antenna height, base id, base latitude, base longitude, base altitude, distance to ref, original latitude, original longitude, original altitude, undulation height, station correction h, inclination correction, pitch, roll, yaw, inclined angle, projected angle, stakeout type, target, station, offset, north diff, east diff, elevation diff.

For the points, lines and polygons you surveyed in point survey, you can export dxf file, then you can edit them in third party CAD software, or import to base map to check, or import to CAD to stake. Choose the data that you want to export including survey point, input point, control point, stake point, line and polygon, and the layer properties include name, code and height.

11:54

81%

←

Custom Format

Format Name

Input

Extension Name

dat >

Field Delimiter

Comma(,) >

File Header

☒

Custom Format Description

Options

Point ID	Point Name
Code	Code Remark
Line Name	Northing
Easting	Elevation
Local Time	Point Attributes

Backspace

OK

Chapter 5 Static Survey

This chapter describes how to conduct static survey through Banff-AL receiver.

For static survey, Banff-AL supports 3 data formats: binary XYZ, Rinex 3.02 and Rinex 3.04. 3AG binary format (*.XYZ) is a raw observation data format and you can convert it to RINEX

5.1 Static Data Collection

Static survey is mainly used for the control point survey. To reach millimeter accuracy, follow as below:


- At least 3 GNSS receivers are required to form a stable triangulation network.
- It is better to collect static data on the known point.
- Power off the receiver before moving to other observation site.
- For the convenience of post-process static observation raw data, record the station name, receiver SN, antenna height, start and end time for each observation site.

The following steps give an example of static survey.


1. Go to **Device>>Static** and **collect** points. Choose the Record mode, there are two record modes and they can record static data at the same time.




2. Options Settings interface: Input Record name and Point name. Set the Collection Interval, Observation Time and Data Format.
3. Turn on/off the **Loop Record** according to your needs. If this option is turned on, the receiver will delete the earliest recorded data to keep recording when the record space is full.




4. Turn on/off the **Auto Record Static** according to your needs. If this option is turned on, the receiver automatically records static data after it is power on.



5. Set the **Record Space** in the end (unit: MB). It will limit the amount of data that receiver record.



6. Click **Start** to start static survey.



5.2 Static Data Download

The raw observation data is saved in internal memory of Banff-AL receiver, when connected with PC via TYPE-C cable, the Banff-AL receiver can work as a USB Flash Disk, which means you can copy the static data to PC directly.

 > USB flash drive (E) > 1-REC1 > 2023293				
	Modified Date	Type	Size	
 1823E00052930339.XYZ	10/20/2023 3:43 AM	XYZ	690 KB	
 1823E00052930344.XYZ	10/20/2023 3:45 AM	XYZ	166 KB	
 1823E00052930345.XYZ	10/20/2023 3:45 AM	XYZ	147 KB	
 1823E00052930547.XYZ	10/20/2023 5:59 AM	XYZ	2,460 KB	
 1823E00052930600.XYZ	10/20/2023 6:28 AM	XYZ	5,183 KB	